



# ET1781A

## V-RIBBED BELT INSTALLATION TOOL KIT



- Allows damage free mounting of flexible multi-ribbed belts, flexible belt drive requires no idler, but these special assembly tools.
- For the straightforward removal and fitting of new flexible V-ribbed belts (e.g. air-conditioning compressor).
- Also suitable for use with double-belt drives.
- Application:
  - BMW 118, 120, 318, 320, 325, 330, 335, 520, 525, 530, 535, 635, 720, X3, X5
  - Audi A3 1.6/ 2.0D
  - Seat Altea, Ibiza 1.6/ 2.0D
  - Skoda Octavia, Yeti 1.6/ 2.0D
  - Volkswagen Eos, Golf, Passat, Polo, Scirocco 2.0D
  - Chrysler Grand Voyager, Voyager 2.5D/ 2.8D
  - Ford C-Max, Focus, C-Max, Mondeo, Tourneo, Transit 1.4/ 1.6/ 1.8/ 2.0 Transit, Transit Tourneo 2.2D, Courier, Fiesta, Fusion 1.6
  - Mazda 3, 5, Axela 1.8/ 2.0 und Modell 2 1.2/ 1.4/ 1.6
  - Mercedes Sprinter, Viano, Vito 3.0D
  - Peugeot 206, 207, 307, Boxer 1.6D /2.2D /3.0D
  - Citroen C2, C3, C4, Jumper, Relay 1.6D/ 2.2D/ 3.0D
  - Fiat Albea, Doblo, Ducato, Fiorino, Fiorino Qubo, Linea, Palio, Siena,Stilo, Strada Pickup 2.2D/ 2.3D/ 3.0D, Doblo, Marea, Multipla 1.6
  - Iveco Daily 2.3D/ 3.0D
  - Volvo C30, S40, V50 1.6/ 1.8/ 2.0
  - Lancia Lybra 1.6
  - Mitsubishi ASX 1.8D