


# E4500

## Air Cutter Shear



Ref. No.	Parts No.	Description	Q'ty	Ref. No.	Parts No.	Description	Q'ty
1	# 160-3	Right Blade	1	24	25-5	Dowel Pin (2.5-5mm)	2
2	# 160-2	Center Blade	1	25	#680-5	Rotor	1
3	# 160-4	Left Blade	1	26	#350-16	Rotor Blade	4
4	# 160-5	Collar	2	27	#680-1	Cylinder	1
5	Z-1024-380	Cap Screw	3	28	#680-2	Rear Plate	1
6	# 160-7	Lock Nut	3	29	626	Ball Bearing	1
7	# 160-1	Cutter Housing incl. Lock Nut	1	30	JS-6	Retaining Ring	1
8	# 160-8	Eccentric Nut	1	31	#680-34	Bearing Cap	1
9	EE-4ZZ	Ball Bearing	1	32	# 120-10	Motor Housing	1
11	#680-7	Spacer	1	33	# 120-18	Trigger	1
12	#680-8	Clamp Nut	1	34	R-M40-60	Set Screw	1
13	#680-9	Internal Gear	1	35	# 120-31	Valve Spring	1
14	EE-3ZZ	Ball Bearing	1	36	P-11	O-Ring	1
15	#680-22	Fiber Washer	1	37	# 120-13	Valve Bushing	1
16	IE-10	Retaining Ring	1	38	P-10	O-Ring	2
17	#680-3	Planet Cage	1	39	# 120-14	Valve Stem	1
18	#680-17	Planet Pin	2	40	P-4	O-Ring	1
19	#680-6	Planet Gear	2	41	25-20	Pin (2.5-20mm)	1
20	1500-11-8	Needle Roller	22	42	# 120-11	Deflector	1
21	6001	Ball Bearing	1	43	JBM30-80	Screw	2
22	608	Ball Bearing	1	44	# 120-17	Inlet Bushing	1
23	#680-4	Front Plate	1				