

INSTRUCTIONS



UNIVERSAL TENSIONING GAUGE FOR CAM BELTS

UNIVERSAL TENSIONING GAUGE FOR CAMBELTS

This tensioning gauge can be used to adjust the tension on the cam belts where the movement of the timing belt is measured by load (Nm). Suitable for use on Cam belts with various belt thickness (For belts other than 5mm thickness see Cam Belt Size below)

- Easy to use
- Clear incremental marking with knurled knob for precise measurement
- Dual scale allows reading from top or bottom of tool (Large and small numbers for compatibility)

ALWAYS USE MANUFACTURERS' RECOMMENDATIONS FOR CAM BELT TENSION AND POSITION OF MEASUREMENT. (E.g. between the timing gear and the water pump pulley).

