




## AUTOMATIC TRANSMISSION CLUTCH SPRING COMPRESSOR



 \* For removing and installing the transmission rear clutch piston snap ring.
\* This tool is adjustable and suitable for most models of American cars and light trucks.