

ET1275B

HINO/ ISUZU/ FUSO / UD

ANCHOR PIN REMOVER (12 TONS HYDRAULIC)



**H.C.B-A3036
AIR PUMP (1600 C.C.)
(Dr. 3/8" ADAPTOR)
(Optional accessory)**

No.	Component Name	Descriptions	Quantity
1	Hydraulic Cylinder	12 Tons	1
2	Cylinder Fixation	Ø 67 x 48 x 150L	1
3	Cylinder Prolongation	Ø 74 x 38 x 53L	1
4	M16 x P1.5 Anchor Pin Extractor	M16 x P2.0 x H17 x M16 x P1.5	1
5	M14 x P1.5 Anchor Pin Extractor	M16 x P2.0 x H17 x M14 x P1.5	1
6	M12 x P1.25 Anchor Pin Extractor	M16 x P2.0 x H17 x M12 x P1.25	1
7	M12 x P1.0 Anchor Pin Extractor	M16 x P2.0 x H17 x M12 x P1.0	1
8	M16 x P1.5 Tap	M16 x P1.5 (SKS)	1
9	M14 x P1.5 Tap	M14 x P1.5 (SKS)	1
10	M12 x P1.25 Tap	M12 x P1.25 (SKS)	1
11	M12 x P1.0 Tap	M12 x P1.0 (SKS)	1

- **Application: HINO/ ISUZU/ FUSO/ NISSAN truck.**



Feature: It is a hard work to remove the pin of the drum brake. It wastes a lot of time removing it. With B1275, the anchor pin will be removed in few seconds!



Install the fixation (No. 2) and prolongation (No. 3).
Connect H.C.B-A3036 or any other suitable air hydraulic pump.
Active the pump, and the anchor pin will be removed in few seconds.
Please be careful when you do this work.



Anchor pin was removed!