

ET1351B

UD 17 TONS TRUCK CRANKSHAFT REAR OIL SEAL INSTALLATION TOOL KIT




BZ6273E


Specification:

No.	Name	Description	Q'ty	Remark
1	Installing guide	D: ϕ 120x36L	1	M14xP1.5
2	Installing plate	D: ϕ 154mmx67L	1	d: ϕ 15
3	Fixing screw	M16xP1.5x35L	2	
4	Center screw	H17, M14xP1.5	1	

- To prevent the crankshaft rear oil seal from being damaged during installation.
- Application: UD truck 17T (1996-2011), FE6TB | FE6TC
- Oil seal genuine #: BZ6273E



Step 1.
Install No.1 (Installing guide),
screw No.3 (Fixing screw).
Put the new oil seal onto it.



Step 2.
After installing No.2 (Installing
plate), screw No.4 (Center screw)
to an appropriate place.



Step 3.
Finishing installing oil seal!