

# ET1766F

## CUMMINS 3.9L, 5.9L ,6.7L FRONT & REAR CRANKSHAFT SEAL REMOVER & INSTALLER MASTER KIT



Cummins 3.9L, 5.9L & 6.7L Front & Rear Crankshaft Seal Remover & Installer With Wear Sleeve Installer Tool Set

Applications include 1989-2016 Cummins 4BT 3.9L, B Series 5.9L, ISB 5.9L 6.7L and QSB 5.9L 6.7L

Includes High-Quality, Made in the TAIWAN, H.C.B Equivalents: A1766 , B1766 , C1766 ,D1766 ,E1766

- C1766 - 3824498 Cummins 3.9L, 5.9L, & 6.7L Front Cover Crankshaft Seal Installer Tool Alt
- D1766 - 3824500 Cummins 3.9L, 5.9L, & 6.7L Front Crankshaft Wear Sleeve Installer Tool Alt
- A1766 - 3164660 Cummins 3.9L, 5.9L & 6.7L Rear Crankshaft Seal Remover & Installer Tool Alt
- E1766 - 3824078 Cummins 3.9L, 5.9L & 6.7L Rear Crankshaft Seal & Wear Sleeve Installer Alt
  - B1766 – 3164659 Cummins 3.9L, 5.9L & 6.7L Front Crankshaft Seal Remover & Installer REMOVER/INSTALLER KIT

This tool set works for seals and wear sleeves such as 3937111, 3904353, 3802820, 3934486, 3926126, & 3925529. There is no tool to remove the rear wear sleeve if you have one.